


BOAPOD™

INSTRUCTIONS FOR USE



SPECIFICATIONS

Max Load: 2.64 lbs.

Weight: 0.71 lbs.

Dimensions: 2.2" x 2.4" x 12.2"




Fig. 1

**INCLUDES SMARTPHONE ADAPTER
AND BLUETOOTH SHUTTER BUTTON**

Setting up BoaPod

The BoaPod™ features flexible legs which can be set up as a traditional tripod (see Fig. 1) or twist the legs into any position to place the tripod anywhere.

Wrap it around a pole or branch, hang it on a fence or place it on an uneven surface (Fig. 2-3).




Fig. 2





Fig. 3

Flexible legs can be positioned to become a table stand for your tablet or book (Fig. 4).

Fig. 4





Important: Make sure BoaPod™ is level and steady before mounting any optic to it.

Mounting Optic to BoaPod

The BoaPod™ comes with a removable 360° fluid ballhead with 1/4 universal mounting screw.



For Use With Ballhead

Screw optic, camera or adapter to thread on top of ball head until tight. To adjust position of ball head, loosen lock by turning counter-clockwise (Fig. 5). Rotate ball head as desired (Fig. 6) and tighten securely.



For Use Without Ballhead

Ball Head can be removed by twisting counter-clockwise (Fig. 7). You can then mount optic, camera or adapter directly to tripod. Turn circular knob counter clockwise to tighten (Fig. 8). To remove, turn circular knob clockwise.



IMPORTANT:

- Do not exceed max load capacity of tripod.
- Remove optic before setting up, taking down, adjusting or transporting your tripod.
- Make sure optic is securely fastened to tripod.
- Do not over-tighten locks as this may damage the locking mechanisms.

Using Phone Adapter

Pull open smart phone adapter and attach to back side of phone (Fig. 9). Thread adapter onto top of ball head until tight (Fig. 10).




Fig. 9




Fig. 10

Phone can be positioned in either landscape (Fig. 11) or portrait position (Fig. 12) using ball head.




Fig. 11





Fig. 12

Using Bluetooth Shutter Button

Enable Bluetooth function on your smart phone. Press and hold camera button on bluetooth remote until "WT-1818" appears on your "My Devices" list. Select "WT-1818" on your "My Devices" list to connect. Bluetooth remote will now act as the shutter button on your smart phone. Shutter button comes with CR2032 lithium battery installed and ready to use.



If you experience any difficulties, please contact us and we will be happy to help you.

In the U.S.A.

Phone: 1-631-963-5000

Email: info@carson.com

In the U.K.

Phone: +44 (0) 1938 557440

Email: uksupport@carson.com

In the E.U.

Phone: +44 (0) 1938 557440

Email: eusupport@carson.com

For warranty information, visit www.carson.com/warranty